



1. Apply Bonding Adhesive to clean substrate and to the back of the membrane. Allow to flash off. While the Bonding Adhesive is flashing off, apply a 3/8" bead of Water Stop below the bottom of the deck or nailer.

2. Once the Bonding Adhesive has flashed off, roll in the membrane, embedding the edge into the bead of Water Stop. Sweep the membrane with a stiff bristle broom to ensure a positive bond with the substrate.

3. Align the Termination Bar with the bottom edge of the membrane, and fasten through the membrane into the vertical substrate with an appropriate fastener every 8" (every other pre-punched hole).

4. Apply All Purpose Sealant to the caulk reservoir of the Termination Bar at the rate of 15 lineal feet per tube.

Note: Peel and Stick TPO membrane has factory applied adhesive on the back of the sheet, eliminating the need for application of Bonding Adhesive as shown above. In lieu of applying Bonding Adhesive to the substrates, apply All Purpose Primer, and allow it to flash off completely prior to installing the Peel and Stick TPO membrane.

## A Roof Edge Termination With A Termination Bar

