

Membranes:

<p>GenFlex[®] Peel & Stick™ TPO (Thermoplastic Polyolefin)</p>	<p>37.7" x 50' (42 lb) Roll; 45 mil thick 6' 3" x 50' (84 lb) Roll; 45 mil thick</p>	<p><i>With adhesive built into the product, GenFlex's Peel & Stick™ TPO system contributes to Energy Star[®] compliance and provides an environmentally friendly installation, free of bonding adhesive fumes.</i></p>
<p>GenFlex[®] TPO (Thermoplastic Polyolefin)</p>	<p>6' 1" x 50' (72 lb) Roll; 45 mil thick 10' x 25' (58 lb) Roll; 45 mil thick</p>	<p><i>GenFlex TPO offers the proven flexibility and weather resistance of EPDM, plus high solar reflectivity. It is environmentally friendly, as well as quick, clean and easy to install.</i></p>
<p>GenFlex[®] EPDM (Ethylene Propylene Diene Monomer)</p>	<p>5' 5" x 100' (168 lb) Roll; 45 mil thick 10' x 25' (77 lb) Roll; 45 mil thick 15' x 25' (115 lb) Roll; 45 mil thick</p>	<p><i>GenFlex EPDM is a high-quality rubber membrane that is resistant to tears, impacts, punctures and normal foot traffic.</i></p>

Accessories:

<p>GenFlex[®] Peel & Stick™ Flashing: FlexWhite TPO EPDM Black</p>	<p>12" x 25' Roll 9" x 25' Roll</p>	<p><i>Flashing is specifically designed to flash pipes, inside corners, outside corners and other surfaces.</i></p>
<p>GenFlex[®] Seam Tape: TPO White EPDM Black</p>	<p>3" x 50' Roll 3" x 50' Roll</p>	<p><i>If you're covering a large area, you can use GenFlex Seam Tape to attach multiple membrane panels together with a high-strength splice.</i></p>
<p>GenFlex[®] Clear (Seam) Primer</p>	<p>1 Quart Can; approx. 50 SF per Quart</p>	<p><i>Seam primer is used to prepare the seam area for membrane, seam tape, and cover tape.</i></p>
<p>GenFlex[®] Peel & Stick™ Pipe Boot: TPO White EPDM Black</p>	<p>1" to 6" Pipe Penetrations 1" to 6" Pipe Penetrations</p>	<p><i>Pre-fabricated Pipe Boots are designed to cover round penetrations on the roof.</i></p>
<p>GenFlex[®] Cover Tape: TPO White EPDM Black</p>	<p>5.5" x 25' Roll 6" x 25' Roll</p>	<p><i>Cover Tape is used to strip in field seams and edge metal flanges.</i></p>
<p>GenFlex[®] Bonding Adhesive: Water Based All Purpose</p>	<p>1 & 3 Gallon Pail; approx. 120 SF per Gallon 1 & 3.5 Gallon Pail; approx. 70 SF per Gallon</p>	<p><i>Bonding Adhesive is used for bonding the membranes to plywood, concrete and insulation. Please keep in mind that Bonding Adhesive is not designed to be used for seaming membrane panels together.</i></p>
<p>GenFlex[®] Substrate Primer</p>	<p>1 Gallon Pail; approx. 200 SF per Gallon</p>	<p><i>Substrate Primer is used to prepare the roof deck for the installation of Peel & Stick TPO membrane.</i></p>
<p>GenFlex[®] Edge Caulk: TPO White EPDM Black</p>	<p>11 oz Tubes; approx. 15 LF per Tube 11 oz Tubes; approx. 15 LF per Tube</p>	<p><i>Use Edge Caulk along all seams, patches, flashings, and pipe boots and at the top of termination bars.</i></p>
<p>GenFlex[®] Water Stop</p>	<p>11 oz Tubes; approx. 15 LF per Tube</p>	<p><i>Apply Water Stop behind the membrane and in conjunction with a termination bar or pipe boot, to create a compression seal.</i></p>
<p>GenFlex[®] #12 Fastener with Plate</p>	<p>100 per Box; approx. 200 SF per Box</p>	<p><i>GenFlex offers 2 7/8" roofing screws and 3" insulation plates for use when installing insulation.</i></p>
<p>GenFlex[®] Termination Bar</p>	<p>1" x 5'</p>	<p><i>Termination Bar is an extruded aluminum bar used to secure and seal the membrane on vertical or horizontal termination details.</i></p>
<p>GenFlex[®] Flashing & Seam Accessory Kit</p>	<p>Contains: 2 handles, 6 scrub pads, 2 dip trays, 1 seam roller, templates for corner & T-joint flashings, application instructions and DVD.</p>	<p><i>This kit contains the necessary accessories to properly assemble seams on a GenTite roof.</i></p>