

1. See Detail G "Cutting In a Penetration".

 Once the deck membrane is installed to the curb or outside wall corner, apply Bonding Adhesive to the vertical substrate to the intended flashing height and to the back of the membrane flashing.
Apply All Purpose Primer to the deck membrane extending 5" from angle change. Allow to flash off.

3. Apply Seam Tape to primed deck membrane tight to the angle change, and roll with the seam roller with release liner still on tape.

4. Align edge of the Peel & Stick flashing or flashing membrane with the Seam Tape, leaving 1/4" of the tape exposed. Press the flashing into the angle change to minimize bridging, and continue up the vertical. Hand roll. Continuously wrap flashing around curb and cut corners to fit square with the curb.

5. Apply All Purpose Primer to the corner flashing area. Allow to flash off.

6. Remove half of the release liner from the Peel & Stick Corner and fold it in half with the tape side exposed. Center and mate the corner to the adhesive on the vertical surfaces. Reach between the folded layers of flashing and press the upper flap into the point of the corner, using the sides of your hands. Pull, tightly flare and stretch the flashing into the angle change onto the horizontal surface. Avoid bridging and gaps. Hand Roll.

7. Apply Edge Caulk to all flashing and seam edges.



## Curb Or Wall Flashing & Outside Corner